

# VERTICAL STAMPING SERIES

## INSTALLATION GUIDE FORM

Thank you for buying Flex Stone products. Prior to installation of the material, please read this form carefully.

### APPLICATION PROCEDURE

- Application of Primer 100 on the surface to ensure durable installation.
- Application of 10mm–12mm of wall mix on the desired wall.
- Imprinting the desired texture and material on the wall surface with polyurethane stamps.
- Once material is dry, coloring process takes place to achieve desired colour
- Final step is application of sealer.

# VERTICAL STAMPING SERIES

## INSTALLATION GUIDE FORM

